

INSTBACKUPCAM



BACKUPCAM

(For use in GMLAN29 vehicles with OEM installed backup cameras)

INTRODUCTION

The BACKUPCAM is designed to retain factory back up cameras to be viewed through the aftermarket radio.

APPLICATIONS

BUICK

Enclave	2008-up
Lucerne	2006-2011

CADILLAC

DTS	2006-2011
Escalade/ESV/EXT	2007-2011
SRX	2007-2009

CHEVROLET

Avalanche	2007-2011
Avalanche <i>without NAV</i>	2012-up
Cheyenne <i>without NAV</i>	2012-up
Equinox	2007-2009
Express	2008-2012
Express <i>without NAV</i>	2013-up
Impala	2006-2013
Monte Carlo	2006-2007
Silverado	2007-2011
Silverado <i>without NAV</i>	2012-2013
Suburban	2007-2011
Suburban <i>without NAV</i>	2012-up
Tahoe	2007-2011

Tahoe <i>without NAV</i>	2012-up
Traverse	2009-up

GMC

Acadia	2007-up
Savana	2008-2012
Savana <i>without NAV</i>	2013-up
Sierra	2007-2011
Sierra <i>without NAV</i>	2012-2013
Yukon	2007-2011
Yukon <i>without NAV</i>	2012-up

HUMMER

H2	2008-2009
----	-----------

PONTIAC

Torrent	2007-2009
---------	-----------

SATURN

Outlook	2007-2010
Vue	2008-2010

SUZUKI

XL-7	2007-2009
------	-----------

INTERFACE INSTALLATION

From the 16-pin harness:

- Connect the Yellow RCA to the back up camera input of the aftermarket radio.



1-800-221-0932



metraonline.com

REV. 10/14/13

© COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

**BACKUPCAM**

(Para el uso en vehículos con GMLAN29 OEM cámaras de seguridad instaladas)

INTRODUCCIÓN

El BACKUPCAM está diseñado para mantener una copia de seguridad de fábrica cámaras para ser visto a través de la radio no original.

APLICACIONES**BUICK**

Enclave	2008 y mas
Lucerne	2006-2011

CADILLAC

DTS	2006-2011
Escalade/ESV/EXT	2007-2011
SRX	2007-2009

CHEVROLET

Avalanche	2007-2011
Avalanche <i>sin NAV</i>	2012 y mas
Chevyenne <i>sin NAV</i>	2012 y mas
Equinox	2007-2009
Express	2008-2012
Express <i>sin NAV</i>	2013 y mas
Impala	2006-2013
Monte Carlo	2006-2007
Silverado	2007-2011
Silverado <i>sin NAV</i>	2012-2013
Suburban	2007-2011
Suburban <i>sin NAV</i>	2012 y mas
Tahoe	2007-2011

Tahoe <i>sin NAV</i>	2012 y mas
Traverse	2009 y mas

GMC

Acadia	2007 y mas
Savana	2008-2012
Savana <i>sin NAV</i>	2013 y mas
Sierra	2007-2011
Sierra <i>sin NAV</i>	2012-2013
Yukon	2007-2011
Yukon <i>sin NAV</i>	2012 y mas

HUMMER

H2	2008-2009
----	-----------

PONTIAC

Torrent	2007-2009
---------	-----------

SATURN

Outlook	2007-2010
Vue	2008-2010

SUZUKI

XL-7	2007-2009
------	-----------

INSTRUCCIONES DE INSTALACIÓN

Desde el arnés de 16 pins:

- Conecte el RCA amarillo a la parte trasera de entrada de cámara de la radio del mercado de accesorios.

**1-800-221-0932****metraonline.com**